

FlexSwitch™ 4FxModel 6530-FK Replacement Kit

User Manual



PRODUCT OVERVIEW

The 6530-FK is the direct replacement for the discontinued FlexSwitch Model 600XC 4Fx. The 6530-FK replacement kit consists of two iConverter Fast Ethernet Fiber-to-Fiber Media Converter Modules installed in an iConverter 2-Module chassis.

The 6530-FK provides four 100BASE-Fx fiber ports supporting half or full duplex operation.

The 6530-FK features front panel accessible DIP-Switches for convenient configuration of the fiber ports. On-board DIP-Switches configure the link mode and backplane operation. The backplanes are enabled by default.

Chassis Models

FlexSwitch Replacement Matrix				
Disconnected Part	Replacement Part			
	Connector Type		Fiber Type	Distance
	SC	ST		
6530-0	6530-0-FK	-	MM	5km
6530-2	6530-2-FK	-	SM	30km
6530-3	6530-3-FK	-	SM	60km
6531-0	-	6531-0-FK	MM	5km
6531-2	-	6531-2-FK	SM	30km

INSTALLATION PROCEDURE

- 1) Configure DIP-Switches
- 2) Install Module in Chassis and Connect Cables
- 3) Installing the Chassis
- 4) Apply AC Power
- 5) Verify Operation

1) Configure DIP-Switches

Front Panel DIP-Switches

The modules have been pre-configured for full duplex operation as illustrated below. For half duplex operation, use the front panel DIP-Switch associated with the appropriate fiber port.




Front Panel DIP-Switches

Port 1 and Port 2 Fiber Full/Half-Duplex

When in the Fiber Full/Half-Duplex DIP-Switch is in the “FDX” position (factory default), the fiber port operates in Full-Duplex mode. When in the “HDX” position, the fiber port operates in Half-Duplex mode and its distance is limited by the IEEE 802.3 standard to 412 meters.

On-Board DIP-Switches

The modules have on-board DIP-Switches for the configuration of the Link Modes and Backplane connectivity. For more information on Link Mode, see the [Link Mode Application Note](#). The modules are pre-configured with the Backplanes enable as shown below.



On-Board DIP-Switches

Backplane Port A Enable/Disable

This DIP-Switch must be in the RIGHT “Enable” position for the module to operate correctly. The switch provides backplane connectivity with the other switch module.

Backplane Port B Enable/Disable

This DIP-Switch must be in the RIGHT “Enable” position for the module to operate correctly. The switch provides backplane connectivity with the other switch module.

Link Propagate/Link Segment

When both the Link Propagate/Link Segment “LP” and the Remote Fault Detect “RFD” DIP-Switches are in the LEFT position, Link Segment mode is enabled.

When the Link Propagate/Link Segment “LP” DIP-Switch is in the RIGHT position, and the Remote Fault Detect “RFD” DIP-Switch is in the LEFT position, Link Propagate mode is enabled.

Note: Setting both the “LP”, “RFD” and “SFD” to the RIGHT positions on the same module is an illegal mode that will result in unpredictable behavior.

Remote Fault Detection

When the Remote Fault Detect “RFD” DIP-Switch is in the RIGHT position, the RFD mode is selected. When in the LEFT position, the RFD mode is disabled.

When the “RFD” and the “LP” DIP-Switches are in the RIGHT position, the RFD+LP mode is selected.

Note: Connecting two converters with both set to RFD mode is an illegal setting and will cause a “deadly embrace” lockup.

Symmetrical Fault Detect

When the DIP-Switch is in the RIGHT position, the Symmetrical Fault Detection “SFD” mode is enabled. When in the LEFT position (factory default), the SFD mode is disabled.

Note: Converter must be deployed in pairs for SFD mode to operate correctly.

2) Install Module in the Chassis and Connect the Cables

The modules are pre-installed in the 2-Module chassis with the backplane enabled on both modules.

- a. Carefully slide the module into an open slot in the chassis. Align the module with the installation guides and ensure that the module is firmly seated against the backplane. Secure the module by fastening the front panel thumbscrew (push in and turn clockwise to tighten) to the chassis front. Verify the “Pwr” LED is ON (indicating the chassis is powered).



- b. Connect an appropriate multimode or single-mode fiber cable to the fiber port of the installed modules. It is important to make sure that the transmit (TX) is attached to the receive side of the device at the other end and the receive (RX) is attached to the transmit side.

3) Installing the Chassis

Wall and Rack Mounting

The 2-Module chassis can be wall/rack mounted by attaching the optional wall/rack mount brackets (8249-0). A 19” Rack Mount Shelf (8260-0) is available to install two 2-Module chassis.

The operating temperature of this equipment is 0 to 50 degrees C. If installed in a closed or multi-unit rack assembly, the operating ambient temperature of the rack must not exceed the maximum rated temperature for the chassis used.

Installation of the equipment should be such that the air flow in the front and back of the unit is not compromised or restricted.

Installing this equipment into a rack in such a way as to make it unstable **may cause injury or death**. Always make sure that the rack you are installing this equipment into is properly secured, stable, balanced and designed to carry the weight and weight distribution of this equipment.

Never use this equipment to carry any weight except its own. Never use it as a shelf to support the weight of other equipment.

4) Apply AC Power

Power source should be available within 5 ft. of the chassis and installed per the National Electrical Code, ANSI/NFPA-70.

This equipment requires a 100-240VAC, 0.5Amp, 50/60Hz power outlet. Appropriate overloading protection should be provided on the AC power source outlets utilized.

Appropriate overloading protection should be provided on all AC power source outlets utilized.

Attach the AC power cord to the back of the chassis. Connect the AC power cords to the AC outlets and switch the outlets ON.

Any installed iConverter modules will illuminate the power LED.

WARNING!!!
NEVER ATTEMPT TO OPEN THE CHASSIS OR SERVICE THE POWER SUPPLY OR FAN MODULE. OPENING THE CHASSIS MAY CAUSE SERIOUS INJURY OR DEATH. THERE ARE NO USER REPLACEABLE OR SERVICEABLE PARTS IN THIS UNIT.



Rear of 2-Module Chassis with Power Cord


5) LED Indicators

Each module has LED indicators to provide connection information.

LED Function “Legend”	Color	OFF	ON
Power “Pwr”	Yellow	No power	Module has power
Port 1 Fiber Duplex “FDX”	Green	Fiber in Half Duplex (when fiber link is active)	Fiber in Full Duplex (when fiber link is active)
Port 1 Fiber Link “Lk/Act”	Green	No fiber link	ON: Fiber link Blinking: Fiber activity
Port 2 Fiber Duplex “FDX”	Green	Fiber in Half Duplex (when fiber link is active)	Fiber in Full Duplex (when fiber link is active)
Port 2 Fiber Link “Lk/Act”	Green	No fiber link	ON: Fiber link Blinking: Fiber activity

LED Indicators

Mechanical



Specifications

Description	4 Port Fast Ethernet Optical Switch
Standards	IEEE 802.3
Regulatory Compliances	Safety: UL, CE, UKCA EMI: FCC Class A ACT: TAA, BAA, NDA
Environmental	RoHS, WEEE, REACH
Frame Size	1,536 bytes
Port Type	100BASE-FX (ST, SC)
Cable Type	Multimode: 50/125µm, 62.5/125µm Single-mode: 9/125µm
AC Power Requirements	100 to 240VAC, 50/60Hz 0.5A @ 120VAC
Dimensions W x D x H	6.7" x 5.51" x 1.87" (435.6 mm x 228.6 mm x 44.5 mm)
Weight	3.0 lbs. (1.36 kg)
Temperature	Commercial: 0 to 50°C Storage: -40 to 80°C
Humidity	5% to 95% non-condensing
Altitude	-100m to 4,000m
Warranty	Lifetime warranty with 24/7/365 free Technical Support

General and Copyright Notice

This publication is protected by U.S. and international copyright laws. All rights reserved. The whole or any part of this publication may not be reproduced, stored in a retrieval system, translated, transcribed, or transmitted, in any form, or by any means, manual, electric, electronic, electromagnetic, mechanical, chemical, optical or otherwise, without prior explicit written permission of Omnitron Systems Technology, Inc.

The following trademarks are owned by Omnitron Systems Technology, Inc.: FlexPoint™, FlexSwitch™, iConverter®, miConverter™, NetOutlook®, OmniLight®, OmniConverter®, RuggedNet®, Omnitron Systems Technology, Inc.™, OST™ and the Omnitron logo.

All other company or product names may be trademarks of their respective owners.

The information contained in this publication is subject to change without notice. Omnitron Systems Technology, Inc. is not responsible for any inadvertent errors.

Warranty

This product is warranted to the original purchaser (Buyer) against defects in material and workmanship for a period of two (2) years from the date of shipment. A lifetime warranty may be obtained by the original purchaser by registering this product at www.omnitron-systems.com/support within ninety (90) days from the date of shipment. During the warranty period, Omnitron will, at its option, repair or replace a product which is proven to be defective with the same product or with a product with at least the same functionality.

For warranty service, the product must be sent to an Omnitron designated facility, at Buyer's expense. Omnitron will pay the shipping charge to return the product to Buyer's designated US address using Omnitron's standard shipping method.

Limitation of Warranty

The foregoing warranty shall not apply to product malfunctions resulting from improper or inadequate use and/or maintenance of the equipment by Buyer, Buyer-supplied equipment, Buyer-supplied interfacing, unauthorized modifications or tampering with equipment (including removal of equipment cover by personnel not specifically authorized and certified by Omnitron), or misuse, or operating outside the environmental specification of the product (including but not limited to voltage, ambient temperature, radiation, unusual dust, etc.), or improper site preparation or maintenance.

No other warranty is expressed or implied. Omnitron specifically disclaims the implied warranties of merchantability and fitness for any particular purpose.

The remedies provided herein are the Buyer's sole and exclusive remedies. Omnitron shall not be liable for any direct, indirect, special, incidental, or consequential damages, whether based on contract, tort, or any legal theory.

Environmental Notices

The equipment covered by this manual must be disposed of or recycled in accordance with the Waste Electrical and Electronic Equipment Directive (WEEE Directive) of the European Community directive 2012/19/EU on waste electrical and electronic equipment (WEEE) which, together with the RoHS Directive 2015/863/EU, for electrical and electronic equipment sold in the EU after July 2019. Such disposal must follow national legislation for IT and Telecommunication equipment in accordance with the WEEE directive: (a) Do not dispose waste equipment with unsorted municipal and household waste. (b) Collect equipment waste separately. (c) Return equipment using collection method agreed with Omnitron.

The equipment is marked with the WEEE symbol shown to indicate that it must be collected separately from other types of waste. In case of small items the symbol may be printed only on the packaging or in the user manual. If you have questions regarding the correct disposal of equipment go to www.omnitron-systems.com/support or e-mail to Omnitron at intlinfo@omnitron-systems.com.



Safety Warnings and Cautions



ATTENTION: Observe precautions for handling electrostatic discharge sensitive devices.



WARNING: Potential damage to equipment and personal injury.



WARNING: Risk of electrical shock.

CUSTOMER SUPPORT INFORMATION

Phone: (949) 250-6510

Fax: (949) 250-6514

Address: Omnitron Systems Technology, Inc.
38 Tesla

Irvine, CA 92618, USA

Email: support@omnitron-systems.com

URL: www.omnitron-systems.com