

Omniconverter[®]

GHPoE/M

Managed 6-Port 60W Pre-BT PoE Gigabit Ethernet Switches



Quick Start Guide

General and Copyright Notice

This publication is protected by U.S. and international copyright laws. All rights reserved. The whole or any part of this publication may not be reproduced, stored in a retrieval system, translated, transcribed, or transmitted, in any form, or by any means, manual, electric, electronic, electromagnetic, mechanical, chemical, optical or otherwise, without prior explicit written permission of Omnitron Systems Technology, Inc.

The following trademarks are owned by Omnitron Systems Technology, Inc.: FlexPoint[™], FlexSwitch[™], iConverter[®], miConverter[™], NetOutlook[®], OmniLight[®], OmniConverter[®], RuggedNet[®], Omnitron Systems Technology, Inc.[™], OST[™] and the Omnitron logo.

All other company or product names may be trademarks of their respective owners.

The information contained in this publication is subject to change without notice. Omnitron Systems Technology, Inc. is not responsible for any inadvertent errors.

Warranty

This network product and the included AC/DC power adapter are warranted to the original purchaser (Buyer) against defects in material and workmanship for a period of two (2) years from the date of shipment. The warranty for the network product (excluding the AC/DC power adapter) can be extended to five (5) years by registering the product at www.omnitron-systems.com/support within ninety (90) days from the date of shipment. During the warranty period, Omnitron will, at its option, repair or replace a product which is proven to be defective with the same product or with a product with at least the same functionality.

For warranty service, the product must be sent to an Omnitron designated facility, at Buyer's expense. Omnitron will pay the shipping charge to return the product to Buyer's designated US address using Omnitron's standard shipping method.

Limitation of Warranty

The foregoing warranty shall not apply to product malfunctions resulting from improper or inadequate use and/or maintenance of the equipment by Buyer, Buyer-supplied equipment, Buyer-supplied interfacing, unauthorized modifications or tampering with equipment (including removal of equipment cover by personnel not specifically authorized and certified by Omnitron), or misuse, or operating outside the environmental specification of the product (including but not limited to voltage, ambient temperature, radiation, unusual dust, etc.), or improper site preparation or maintenance.

No other warranty is expressed or implied. Omnitron specifically disclaims the implied warranties of merchantability and fitness for any particular purpose.

The remedies provided herein are the Buyer's sole and exclusive remedies. Omnitron shall not be liable for any direct, indirect, special, incidental, or consequential damages, whether based on contract, tort, or any legal theory.

Environmental Notices

The equipment covered by this manual must be disposed of or recycled in accordance with the Waste Electrical and Electronic Equipment Directive (WEEE Directive) of the European Community directive 2012/19/EU on waste electrical and electronic equipment (WEEE) which, together with the RoHS Directive 2015/863/EU, for electrical and electronic equipment sold in the EU after July 2019. Such disposal must follow national legislation for IT and Telecommunication equipment in accordance with the WEEE directive: (a) Do not dispose waste equipment with unsorted municipal and household waste. (b) Collect equipment waste separately. (c) Return equipment using collection method agreed with Omnitron.



The equipment is marked with the WEEE symbol shown to indicate that it must be collected separately from other types of waste. In case of small items the symbol may be printed only on the packaging or in the user manual. If you have questions regarding the correct disposal of equipment go to www.omnitron-systems.com/support or e-mail to Omnitron at intlinfo@omnitron-systems.com.

Safety Warnings and Cautions



ATTENTION: Observe precautions for handling electrostatic discharge sensitive devices.



WARNING: Potential damage to equipment and personal injury.



WARNING: Risk of electrical shock.

OmniConverter[®] GHPoE/M

Quick Start Guide

Product Overview

The OmniConverter GHPoE/M are compact High-Power PoE Ethernet switches that feature copper or fiber uplink ports and four 10/100/1000 RJ-45 copper Power Sourcing Power-over-Ethernet user ports.

The GHPoE/M is a pre-IEEE 802.3bt switch featuring up to 60W per user port models.

The mode of operation can be configured using easily accessible DIP-switches or using Web, Telnet, SSH, SNMPv1/v2c/v3 or Serial Console management interfaces. These management interfaces provide access to filtering and security options, such as, broadcast storm prevention, IGMP, IEEE 802.1x, RADIUS, TACACS+ and Access Control Lists. Email event notification and alarm reporting is provided using Simple Mail Transfer Protocol. To access the user manuals for the Web Interface (3xxxUM-02x Web Interface OmniConverter RuggedNet Switches) and Command Line Interface (3xxxUM-01x Command Line Interface OmniConverter RuggedNet Switches), access the product pages at: www.omnitron-systems.com.

Front Panel

The front of the module provides access to the management (serial console), RJ-45 PoE and uplink ports.


RJ-45 PoE, Uplinks and Fixed-Fiber Ports

The RJ-45 PoE Ethernet user port supports 10BASE-T, 100BASE-TX and 1000BASE-T protocols, auto-negotiation, auto MDI/MDI-X crossover and can be manually forced to a specific speed and duplex mode.

The module is available with one or two gigabit SFP transceiver uplink ports or two 10/100/1000BASE-T RJ-45 copper uplink ports or two LC fixed gigabit fiber uplink ports.

The SFP ports support SERDES 1000BASE-X fiber transceivers (multimode, single-mode and single-mode single-fiber) and SGMII 10/100/1000BASE-T copper transceivers. The SFP interfaces operate in auto-negotiation and support full duplex operation.

Fixed-fiber 1000BASE-X connectors are available with multimode (MM) dual fiber, single-mode (SM) dual fiber and single-mode single-fiber (SF) options. Dual fiber options are available with ST, SC and LC connectors. Single-fiber options are available with SC connectors.




Front Panel Layout

Serial Console Port

To configure the module using the serial port, attach a DB-9 serial (RS-232) equipped computer with terminal emulation software such as Procomm or Putty to the serial port on the module using a RJ-45 to DB-9 serial cable (not included). Some computers do not come with DB-9 serial port connectors and may require a USB-to-serial port adapter.

The port is a standard RS-232 asynchronous serial interface. The serial ports is configured for 57,600bps, 1 stop, 8 data, parity none. The serial adapter cable pin-outs are illustrated below.



Standard RJ-45 to DB-9 serial cable pin-out

Reset Button


A Reset Button is available on the front of the switch to restore the switch to factory default values. Press and hold the reset button for more than 5 seconds to restore the switch to factory default values.

Installation Procedure

- 1) Configure DIP-switches
- 2) Installing the Module
- 3) Apply Power
- 4) Connect Cables
- 5) Verify Operation

1) Configure DIP-switches

The DIP-switches are located on the side of the module. The DIP-switches are used to configure modes of operation, networking features and PoE reset.



DIP-switch Bank Locations

The table below provides a description of each DIP-switch position and function.

Switch	Position	Function
SW1 & SW2	DOWN	Mode of Operation
	UP	
SW3 & SW4	DOWN	Uplink Redundancy
	UP	
SW5	DOWN	MAC Learning (factory default)
	UP	OFF - MAC Learning Disabled
SW6	DOWN	OFF - PoE Forced Disabled (factory default)
	UP	PoE Forced Enabled
SW7	DOWN	L2CP Tunnel (factory default)
	UP	L2CP Tunnel Discard
SW8	DOWN	OFF - PoE Reset
	UP	PoE Reset

DIP-switch Definitions

SW1 and SW2: Mode of Operation

The module supports Switch, Directed Switch and Dual Device modes.

The modes are described with MAC learning enabled. When MAC learning is disabled, unicast packets are forwarded to all ports.

SW1	SW2	1 Uplink Port	2 Uplink Ports
		Function	
DOWN	DOWN	Switch Mode (factory default)	Switch Mode (factory default)
DOWN	UP	Directed Switch Mode	Directed Switch Mode (AKA Camera Mode)
UP	DOWN	Reserved	Dual Device Mode - Switch Mode
UP	UP	Reserved	Dual Device Mode - Directed Switch Mode


Modes of Operation

Switch Mode

When configured for Switch Mode (factory default), the module operates as a standard layer 2 switch. Data flow will follow MAC address mapping.


Directed Switch Mode (AKA Camera Mode)

When configured for Directed Switch Mode, traffic from ports P1 - P4 is only forwarded to the uplink port F1, preventing the broadcast traffic from flooding other network ports. Incoming traffic from F1 follows MAC address mapping.




Directed Switch Mode Single Fiber Uplink Port

For models with two uplink ports (copper or fiber), the data traffic on the additional uplink port (F2) is also forwarded to port F1.



Directed Switch Mode Dual Uplink Ports

When models with two uplink ports are configured for Directed Switch Mode and Uplink Redundancy (per DIP-switches 3 and 4), traffic is forwarded to both the primary and secondary uplink ports. The secondary port will block all traffic while the primary port is active. When the primary port goes down, the secondary port will be active and all traffic will be forwarded out the secondary port (F2).




Directed Switch Mode with Uplink Redundancy

Dual Device Mode


Dual Device Mode is only supported on models with two uplink ports.

When configured for Dual Device Mode, the module is configured as two logically independent Layer 2 switches. Port F1 is associated with ports P1 and P2 and Port F2 is associated with ports P3 and P4. Data flow will follow MAC address mapping.



Dual Device Mode

Configured for Dual Device Mode and Directed Switch Mode, the traffic from ports P1 and P2 is only forwarded to uplink port F1 and ports P3 and P4 are only forwarded to uplink port F2. This prevents broadcast traffic from flooding other network ports. Incoming traffic from F1 and F2 follows MAC address mapping.



Dual Device with Directed Switch Mode

SW3 and SW4: Uplink Redundancy


Uplink redundancy mode is only supported on models with two uplink ports.

The modes are described with MAC learning enabled. When MAC learning is disabled, the module will send data to all ports.

SW3	SW4	1 Uplink Port	2 Uplink Ports
		Function	
DOWN	DOWN	Reserved	Switch Mode (factory default)
DOWN	UP	Reserved	Switch Mode (factory default)
UP	DOWN	Reserved	Uplink Redundancy Mode - no return to primary (F1)
UP	UP	Reserved	Uplink Redundancy Mode - return to primary (F1)

Uplink Redundancy

When configured for Uplink Redundant Mode “no return to primary”, the uplink ports operate as redundant links. A fault on the primary Port F1, will cause a fail over to the secondary Port F2 within 50msec. Port F1 will become the secondary port once the failure condition has been restored because “no return to primary” has been selected.



Redundant Uplink with Switch Mode

When configured for Uplink Redundant Mode “return to primary”, a fault on the primary Port F1, will cause a fail over to the secondary Port F2 within 50msec. The module will return to the primary Port F1 after the failure condition has been restored for 6 seconds.

SW5: MAC Learning - “MAC Learning/Off”

When this DIP-switch is in the DOWN “MAC Learning” position (factory default), all ports on the module will learn the source MAC address of each received packet and store the address so packets destined for the stored addresses can be forwarded to the appropriate port on the module. When the DIP-switch is in the UP “Off” position, learning is turned off and all received unicast packets are forwarded to all ports.

SW6: Forced PoE - “Off/ PoE Forced”

This DIP-switch allows the PoE power to be forced ON when connected to a PD with non-standard detection characteristics. The DIP-switch controls the forced capability for the RJ-45 user ports on the module.

When this DIP-switch is in the DOWN “Off” position, all RJ-45 user ports will automatically perform the detection, classification and powering functions for the attached PD. When this DIP-switch is in the UP “PoE Forced” position, all RJ-45 user ports will provide a maximum of 60 or 100 watts of power to the PD.

SW7: L2CP - “L2CP Tunnel/Discard”

When this DIP-switch is in the DOWN “L2CP Tunnel” position (factory default), all L2CP frames will be tunneled through the module. When this DIP-switch is in the UP “Discard” position, all L2CP frames will be discarded.

SW8: PSE Reset - “Off/PoE Reset”

The module can be configured to disable (reset) the PoE output power for 5 seconds after a loss of receive link on any uplink port. This feature is typically used to allow a PD to re-initialize after a failure on the incoming uplink.

When this DIP-switch is in the DOWN “Off” position (factory default), PoE output power does not reset on a loss of receive link on any uplink port. When this DIP-switch is in the UP “PoE Reset” position, the module will disable PoE output power for 5 seconds following a loss of receive link on any uplink port.

When uplink redundancy is enabled, the loss of link on either F1 or F2 will not cause the PD to be re-initialized even though the PSE Reset is enabled. The PD will be re-initialized on a loss of receive link on both uplink ports.

When Dual Device Mode is enabled, the loss of receive link on a uplink port will re-initialize the PDs associated with the that uplink port. Ports P1 and P2 will drop PoE power when a loss of receive link on F1 is detected and ports P3 and P4 will drop PoE power when a loss of receive link on F2 is detected.

2) Installing the Module

Wall Mounting

The wall mounting height of the module should be less than or equal to 2 meters (6.6 feet) from the floor. Use the four mounting holes on the module to secure the module to the wall. The module can accommodate #6 screws (not included).

Installation of the module should be such that the air flow in the front, back, side and top vents of the switch are not compromised or restricted.

The accessory cables should have their own strain relief and do not pull down on the module.

Rack Mounting

The module can be rack mounted using the optional Rack Mount Shelf (8260-0). Refer to the Rack Mount Shelf user manual (040-08260-001x) for the proper installation guidelines.


Follow the same guidelines above when rack mounting the module.

3) Apply Power

AC Power

Secure the ground wire to the ground screw. See the figure below for the location of the grounding screws.

Route the power cord through the provided strain relief for additional support and connect the DIN connector at the end of the wire on the AC/DC adapter to the DIN connector on the module. Connect the AC/DC adapter to the AC outlet. Confirm that the module has powered up properly by checking the Power LED located on the front of the switch.



AC Models Rear View: DIN Connector for AC/DC Power Adapter

Make sure to disconnect the power and ground cables before removing the module.

WARNING!!!
NEVER ATTEMPT TO OPEN THE CHASSIS OR SERVICE THE POWER SUPPLY. OPENING THE CHASSIS MAY CAUSE SERIOUS INJURY OR DEATH. THERE ARE NO USER REPLACEABLE OR SERVICEABLE PARTS IN THIS UNIT.


DC Power

This module is intended for installation in restricted access areas. (“Les matériels sont destinés à être installés dans des EMBLEMES À ACCÈS RESTREINT”). A restricted access area can be accessed only through the use of a special key, or other means of security.

Power source should be available within 5 ft. of the chassis. The over current protection for connection with centralized DC shall be provided in the building installation, and shall be a UL listed circuit breaker rated 20 Amps, and installed per the National Electrical Code, ANSI/NFPA-70.

The GHPoE/M requires +50 to +57VDC inclusive of tolerances (4.46A @ 56VDC max rated power). See specification table for specific model requirements.

Appropriate overloading protection should be provided on the DC power source outlets utilized.



DC Models Rear View: 2-Pin Terminal for DC Power

WARNING: Only a DC power source that complies with safety extra low voltage (SELV) requirements can be connected to the DC-input power supply.

WARNING REGARDING EARTHING GROUND:

- This equipment shall be connected to the DC supply system earthing electrode conductor or to a bonding jumper from an earthing terminal bar or bus to which the DC supply system earthing electrode is connected.
- This equipment shall be located in the same immediate area (such as adjacent cabinets) as any other equipment that has a connection between the earthed conductor of the same DC supply circuit and the earthing conductor, and also the point of earthing of the DC system. The DC system shall not be earthed elsewhere.
- The DC supply source is to be located within the same premises as this equipment.
- There shall be no switching or disconnecting devices in the earthed circuit conductor between the DC source and the earthing electrode conductor.


Locate the DC circuit breaker of the external power source, and switch the circuit breaker to the OFF position.

Prepare a power cable using a three conductor insulated wire (not supplied) with 12AWG to 14AWG thickness. Cut the power cable to the length required.

Strip approximately 3/8 of an inch of insulation from the power cable wires.

Connect the ground wire to the grounding screws on the back of the module.


Connect the power cables to the module by fastening the stripped ends to the DC power connector.



DC Models Rear View: Power Connections

WARNING: The positive lead of the power source must be connected to the “+” terminal on the module and the negative lead of the power source to the “-” terminal on the module as shown above.

The power connections on the module are isolated. This provides support of positive or negative power connections.



Power Options

WARNING: Note the wire colors used in making the positive, negative and ground connections. Use the same color assignment for the connection at the circuit breaker.

Connect the power wires to the circuit breaker and switch the circuit breaker ON. If any module are installed, the Power LED will indicate the presence of power.

During the installation, ensure that the ground potentials are maintained throughout the system connections. This includes but not limited to the power source ground and any shielded cabling grounds.

WARNING!!!
 NEVER ATTEMPT TO OPEN THE CHASSIS OR SERVICE THE POWER SUPPLY. OPENING THE CHASSIS MAY CAUSE SERIOUS INJURY OR DEATH. THERE ARE NO USER REPLACEABLE OR SERVICEABLE PARTS IN THIS UNIT.

Make sure to disconnect the power and ground cables before removing the equipment.

4) Connect Cables

- a. When using SFP models, insert the SFP fiber transceiver into the SFP receptacle on the front of the module (see the SFP Data Sheet 091-17000-001 for supported Gigabit transceivers).

NOTE: The release latch of the SFP fiber transceiver must be in the closed (up) position before insertion.

- b. Connect an appropriate multimode or single-mode fiber cable to the fiber port on the front of the module. It is important to ensure that the transmit (TX) is attached to the receive side of the transceiver at the other end and the receive (RX) is attached to the transmit side. When using single-fiber (SF) models, the TX wavelength must match the RX wavelength at the other end and the RX wavelength must match the TX wavelength at the other end.
- c. Connect the Ethernet 10/100/1000 RJ-45 port using a Category 5 or better cable to an external 10BASE-T, 100BASE-TX or 1000BASE-T Ethernet device.

Description	15W IEEE 802.3af PoE	30W IEEE 802.3at PoE+	60W Pre-BT
Power Supply Voltage Range	46.0 to 57.0 VDC	51.0 to 57.0 VDC	51.0 to 57.0 VDC
Voltage Range at PSE port Output	44.0 to 56.0 VDC	50.0 to 56.0 VDC	50.0 to 56.0 VDC
Maximum Power from PoE/PSE port	15.4 watts	30 watts	60 watts
Minimum Voltage at PoE/PD port input*	37.0 VDC	42.5 VDC	42.5 VDC
Minimum Power at PoE/PD port*	12.95 watts	25.5 watts	51 watts
* at 100 meters using Cat5			

5) Verify Operation

Verify the module is operational by viewing the LED indicators.

Power LED Indicators		
Legend	Indicator	Description
Pwr	OFF	Unit not powered
	Amber - ON	Input voltage below or above nominal range
	Green - ON	Unit powered
	Green - Blinking at 1Hz	Indicates reset button has been pressed for more than 5 seconds and the module is ready to be restored to factory default values

Power LED Indicators

Uplink Ports LED Indicators - SFP and Copper Uplink Models		
Legend	Indicator	Description
10 (100+1000)	OFF	No link
	Green - ON	Port linked at 10Mbps
	Green - Blinking at 10Hz	Port data activity at 10Mbps
	Green - Blinking at 1Hz	Port linked at 10Mbps and in redundant secondary mode
100	OFF	No link
	Amber - Blinking at 1Hz	Port linked at 100Mbps and receiving Far End Fault Indicator (FEFI)
	Green - ON	Port linked at 100Mbps
	Green - Blinking at 10Hz	Port data activity at 100Mbps
	Green - Blinking at 1Hz	Port linked at 100Mbps and in redundant secondary mode
1000	OFF	No link
	Amber - Blinking at 1Hz	Port not linked at 1000Mbps and receiving AN Remote Fault
	Green - ON	Port linked at 1000Mbps
	Green - Blinking at 10Hz	Port data activity at 1000Mbps
	Green - Blinking at 1Hz	Port linked at 1000Mbps and in redundant secondary mode

Uplink LED Indicators - SFP and Copper Models

Fiber Ports LED Indicators - Fixed Fiber Models		
Legend	Indicator	Description
1000	OFF	No link
	Amber - Blinking at 1Hz	Port not linked at 1000Mbps and receiving AN Remote Fault
	Green - ON	Port linked at 1000Mbps
	Green - Blinking at 10Hz	Port data activity at 1000Mbps
	Green - Blinking at 1Hz	Port linked at 1000Mbps and in redundant secondary mode

Fiber LED Indicators - Fixed Fiber Models

RJ-45 User Ports LED Indicators		
Legend	Indicator	Description
10 (100+1000)	OFF	No link
	Amber -ON	Port linked at 10Mbps Half-duplex
	Amber - Blinking at 10Hz	Port data activity at 10Mbps Half-duplex
	Green - ON	Port linked at 10Mbps
	Green - Blinking at 10Hz	Port data activity at 10Mbps
100	OFF	No link
	Amber -ON	Port linked at 100Mbps Half-duplex
	Amber - Blinking at 10Hz	Port data activity at 100Mbps Half-duplex
	Green - ON	Port linked at 100Mbps
	Green - Blinking at 10Hz	Port data activity at 100Mbps
1000	OFF	No link
	Amber -ON	Port linked at 1000Mbps Half-duplex
	Amber - Blinking at 10Hz	Port data activity at 1000Mbps Half-duplex
	Green - ON	Port linked at 1000Mbps
	Green - Blinking at 10Hz	Port data activity at 1000Mbps
PoE/PSE	OFF	Port PSE inactive
	Amber - ON	Port PSE inactive due to power demand exceeding the power source
	Green - single blink	Powered by 802.3af PoE 15W
	Green - two blinks	Powered by 802.3at PoE 30W
	Green - three blinks	Powered by High-Power PoE 60W

RJ-45 LED Indicators

NOTE: The PSE LED may turn Amber (ON) when a non-PD device is connected to the port.

NOTE: When disconnecting and reconnecting the cable from the RJ-45 PSE ports, it is required to wait at least 5 seconds before reconnecting the cable to the RJ-45 PSE port.

Specifications

Description	OmniConverter® GHPoE/M (60W Pre-BT) 10/100/1000BASE-T with Gigabit Fiber or Copper Uplinks Managed 6 Port High-Power PoE Ethernet Switch
Standard Compliances	IEEE 802.3, IEEE 802.1Q, IEEE 802.1ad, IEEE 802.1ab, IEEE 802.1ax, IEEE 802.1w RSTP/MSTP, RFC 5424, RFC 4541, RFC 2710, IEC 624339-2, SMTP, SMS, SNTP, RADIUS, TACACS+, IEEE 802.1x, IEEE 802.3af (15.40 watts max), IEEE 802.3at (30 watts max), High Power 60W PoE
Environmental	REACH, RoHS and WEEE
PoE Modes	IEEE Alternate A (Alt A) and 4-Pair
Management	IPv4 and IPv6 address Web, Telnet, SSH, SNMPv1/v2c/v3 In-Band management via Ethernet port Out-of-band management via serial port
Frame Size	Up to 10,240 bytes
Port Types	Copper: 10/100/1000BASE-T (RJ-45) Fiber: Fixed: ST, SC, LC 1000BASE-X Fiber SFP: 10/100/1000BASE-T SGMII Copper Transceiver or 1000BASE-X Fiber Transceiver Serial: RS-232 (RJ-45)
Cable Types	Copper: EIA/TIA 568A/B, Cat 5 UTP and higher Fiber: Multimode: 50/125, 62.5/125µm Single-mode: 9/125µm Serial: Category 3 and higher
AC Power Requirements (Models with AC/DC Adapters)	100 - 240VAC 50/60Hz 3.5A max at 115VAC 2.5A max at 230VAC Supplied adapter provides 250W
DC Power Requirements (Models with DC Terminals)	+46 to +57VDC; inclusive of tolerances 4.46A @ 56VDC 2 Pin Terminal (non-isolated)
Dimensions (W x D x H)	6.28" x 5.2" x 1.5" (159.5 mm x 132.1 mm x 38.1 mm)
Weight	Module Only: 1.6 lbs.; 735 grams Module with AC/DC Adapter: 3.7 lbs.; 1703 grams
Operating Temperature (See Temperature Derating Table)	Commercial: 0 to 50°C Wide: -40 to 60°C (-20°C AC cold start) Extended: -40 to 75°C - not available for models with AC/DC Adapters Storage: -40 to 80°C
Humidity	5 to 95% (non-condensing)
Altitude	-100m to 4,000m (operational)
MTBF (hours)	Module Only: 266,000 AC/DC Adapter: 100,000
Warranty	5 year product warranty with 24/7/365 free Technical Support 2 year AC power adapter warranty

Regulatory Compliances	Safety:	UL 62368-1, UL 60950-1, IEC 62368-1, IEC 60950-1, EN 62368-1, EN 60950-1, CAN/CSA C22.2 No. 62368-1-14, CAN/CSA C22.2 No. 60950-1, CE Mark
	EMC:	EN 55032/24 CE Emissions/Immunity, IEC 61000-6-4 Industrial Emissions, IEC 61000-6-2 Industrial Immunity
	EMI:	CISPR 32, FCC 47 Part 15 Subpart B Class A
	EMS:	IEC 61000-4-2 ESD: Contact: 6 kV; Air: 8 kV, IEC 61000-4-3 RS: 80 MHz to 1 GHz: 10 V/m, IEC 61000-4-4 EFT: Power: 2 kV; Signal: 1 kV (DC models), IEC 61000-4-4 EFT: Power: 1 kV; Signal: 1 kV (AC models), IEC 61000-4-5 Surge: Power: 2 kV; Signal: 2 kV (DC models), IEC 61000-4-5 Surge: Power: 1 kV Line/Line; 2 kV Line/Gnd; Signal: 2 kV (AC models), IEC 61000-4-6 CS: Signal: 10 V, IEC 61000-4-8 (Magnetic Field) 30A/m, IEC 61000-4-11 (Voltage Dips, interrupts)
	IP Rating:	IP20 Protection

AC/DC Adapter Temperature Derating - Total Available Wattage to RJ-45 Ports				
Model	Watts Required	40°C	50°C	60°C
GHPoE/M 60W	240 watts	Full Power	175 watts	115 watts

The AC/DC Adapter Temperature derating table is not applicable to models with DC Terminal. The DC Terminal models will provide full PoE power over the operating temperature range of the module as long as the DC input power meets the requirements stated in the specification table.

Customer Support Information

If you encounter problems while installing this product, contact Omnitron Technical Support:

Phone: (949) 250-6510
Fax: (949) 250-6514
Address: Omnitron Systems Technology, Inc.
38 Tesla
Irvine, CA 92618, USA
Email: support@omnitron-systems.com
URL: www.omnitron-systems.com

Intentionally left blank