

iConverter® X21 User Manual



DESCRIPTION


The iConverter X21 is a X.21 or RS-530 serial to fiber media converter featuring several configuration modes enabling connection to a wide variety of X.21 and RS-530 applications

The X21 can auto-detect and configure itself to match the baud rate of the connected device up to 8.192Mbps. The X21 supports standard DCE-sourced timing and terminal timing. The X21 also supports RS-530 DCE and DTE co-directional timing, Tx and Rx data, and two control lines. An adapter cable is included to accommodate different gender connectors. The X21 features local loopback on the serial and fiber ports to facilitate testing and installations

The X21 supports Small Form Pluggable (SFP) transceivers, enabling adaptability to different fiber types. distances and wavelengths, providing maximum flexibility across a variety of network architectures and topologies.

See data sheet for available models

DIP-SWITCH SETTINGS



Front Panel DIP-switches SW1 - DCE/DTE

When this DIP-switch is in the OFF "DCE" (default) position, the serial port is configured to connect to a DCE device. When the DIP-switch is in the ON "DTE" position, the serial port is configured to connect to a DTE device.

SW2 - Receive Clock Polarity "RC/Inv"

When this DIP-switch is in the OFF "RC" (default) position, the clock edge used to sample the data on the serial port is defined by the TIA/EIA-334-C specification. When the DIP-switch is in the ON "Inv" position, the data on the serial port is sampled on the inverted clock edge

SW3 - DTE Terminal Timing Clock Polarity "TTC/Inv"

When Terminal Timing mode is enabled, this DIP-switch will determine the clock edge used to transfer data. When the DIP-switch is in the OFF "TTC" (default) position, the clock edge used to sample the data on the serial port is defined by the TIA/EIA-334-C specification. When the DIP-switch is in the ON "Inv" position, the data on the serial port is sampled on the inverted clock edge

SW4 - Loopback "Norm/LB"


When the DIP-switch is in the ON "LB" position, the serial port data signals are looped back to the attached device. At the same time, the fiber port is looped. If the module has Terminal Timing enabled (see On-Board DIP-switches), the clock signals are also looped back to the attached device.


Page 1


LED INDICATORS

LED Color Description Pwr Amber OFF: Module is not powered ON: Module has power Fiber Act "P1" Green OFF: No signal detected ON: Signal detected Blinking: Data received Fiber Error "Er" Amber OFF: No error detected ON: Error detected on fiber No clock or corrupted messages Serial Port "Ere" Green OFF: No configured for DCE-facing				
Pwr ON: Module has power Fiber Act "P1" Green OFF: No signal detected ON: Signal detected Blinking: Data received Fiber Error "Er" Amber OFF: No error detected OFF: No error detected on fiber No clock or corrupted messages Serial Port Green OFF: Not configured for DCE-facing	LED	Color	Description	
Fiber Act "P1" Green OFF: No signal detected ON: Signal detected Blinking: Data received Fiber Error "Er" Amber OFF: No error detected ON: Error detected on fiber No clock or corrupted messages Serial Port Green OFF: Not configured for DCE-facing	Diar	Amber	OFF: Module is not powered	
Fiber Act "P1" Green ON: Signal detected Blinking: Data received Fiber Error "Er" Amber OFF: No error detected ON: Error detected on fiber No clock or corrupted messages Serial Port Green OFF: Not configured for DCE-facing	F WI		ON: Module has power	
P1" Green ON: Signal detected Blinking: Data received Fiber Error "Er" Amber OFF: No error detected ON: Error detected on fiber No clock or corrupted messages Serial Port Green OFF: Not configured for DCE-facing	Eiber Act		OFF: No signal detected	
Blinking: Data received Fiber Error "Er" Amber OFF: No error detected ON: Error detected on fiber No clock or corrupted messages Serial Port Green OFF: Not configured for DCE-facing		Green	ON: Signal detected	
Fiber Error "Er" Amber ON: Error detected on fiber No clock or corrupted messages Serial Port Green OFF: Not configured for DCE-facing	F 1		Blinking: Data received	
"Er" Amber ON: Error detected on fiber No clock or corrupted messages Serial Port Green OFF: Not configured for DCE-facing	Liber Free	Amber	OFF: No error detected	
No clock or corrupted messages Serial Port Green OFF: Not configured for DCE-facing			ON: Error detected on fiber	
Green	LI		No clock or corrupted messages	
	Serial Port	Green	OFF: Not configured for DCE-facing	
"DCE" ON: Configured for connection to DCE	"DCE"	Green	ON: Configured for connection to DCE	
Serial Port Green OFF: Not configured for DTE-facing	Serial Port	Croon	OFF: Not configured for DTE-facing	
"DTE" ON: Configured for connection to DTE	"DTE"	Gleen	ON: Configured for connection to DTE	
Timing Green OFF: No activity. No clock detected	Timing	Creen	OFF: No activity. No clock detected	
"TD/RD" Green Blinking: Activity	"TD/RD"	Green	Blinking: Activity	
Loopback Green OFF: Loopback not enabled	Loopback	OFF: Loopback not enabled		
"LB" Blinking: Module in loopback	"LB"	Green	Blinking: Module in loopback	

Page 2







Bank 1 DIP-Switches

SW1 -Terminal Timing

When this DIP-switch is in the DOWN (default) position, Terminal Timing is disabled. When this DIP-switch is in the UP position. Terminal Timing is enabled.

When Terminal Timing disabled, it uses the 'Signal Element Timing' clock (SET clock, circuit S, X.21 pin pair 6, 13) as supplied by the DCE device to time Transmit data (TXD) and Receive data (RXD). This is called Contradirectional Timing. When Terminal Timing is enabled, it uses 'DTE Signal Element Timing' clock (DTE SET clock, circuit X, X.21 pin pair 7, 14) as supplied by the DTE device to time TXD, and uses 'Signal Element Timing' clock to time RXD. This is called Co-directional Timing.

When Terminal Timing is used, both the local and remote media converter must be set to use Terminal Timing, as well as the devices connected to each converter.

SW2, SW3 and SW4 - Reserved

Leave these DIP-switches in the DOWN (factory default) position.

Page 3

SPECIFICATIONS

Standard	ITU-T X.21			
	Safety:	UL, CE, UKCA		
Regulatory	EM:	FCC Class A		
	ACT:	TAA, BAA, NDAA		
Environmental	RoHS, WEEE, REACH			
Data Rate	up to 8,192Mbps			
Port Types	Serial: High-Density 15 Pin Female DB-15 male and female adapters included			
i on types	Fiber: ST, S	C, LC or SFP (depending on model)		
	Serial: 24 gauge (typical)			
Cable Types	Fiber: Multimode: 50/125µm, 62.5/125µm Single-mode: 9/125µm			
AC Power Requirements	AC Adapter:	100 - 240VAC/50 - 60Hz 0.05A @ 120VAC		
DC Power Requirements	DC Input: (Terminal)	5 - 32VDC, 0.3A @ 9VDC 2-Pin Terminal (non-isolated)		
	DC Input: (AC Adapter)	5 - 32VDC, 0.3A @ 9VDC 2.5mm Barrel Connector		
Dimensions W x D x H	Standalone: 3.1" x 4.8" x 1.0" (78.7 mm x 121.9 mm x 25.4 mm) Standalone with Integrated Brackets: 3.8" x 4.8" x 1.0" (96.5 mm x 121.9 mm x 25.4 mm)			
	1.0 lb. (453.6 grams) - without AC Adapter			
Weight	1.5 lbs. (680.4 grams) - with AC Adapter			
Temperature	Commercial: Wide: Storage:	0 to 50°C -40 to 60°C -40 to 80°C		
Humidity	5 to 95% (non-condensing)			
Altitude	-100m to 4,000m			
MTBF (hrs)	510,000 - Module 250,000 - Module with US AC Adapter 100,000 - Module with Universal AC Adapter			
Warranty	Lifetime warranty with 24/7/365 free Technical Support			

MOUNTING AND CABLE ATTACHMENT

Caution: Use proper ESD protection to reduce the risk of damage to your equipment

1. The standalone module is available with or without integrated mounting brackets. When using the standalone module with integrated mounting brackets, use the four mounting holes on the module to secure the module to the wall. The module can accommodate #6 screws (not included)

Standalone modules without mounting brackets can use the optional mounting bracket kit (2x 4381). Use the four mounting holes on the module to secure the module to the wall. The module can accommodate #6 screws (not included)

A 19" Rack Mount Shelf (8260-0) is available to install four X21 modules side by side

Installation of the module should be such that the air flow in the front, back, side and top vents of the switch are not compromised or restricted

For AC models:

To power the unit using the AC/DC adapter, connect the AC/DC adapter to an AC outlet. Then connect the barrel plug at the end of the wire on the AC/DC adapter to the 2.5mm DC barrel connector (center-positive) on the unit. Confirm that the unit has powered up properly by checking the power status LED located on the front of the unit.

For DC Models:

To power the unit using a DC power source, prepare a power cable using a two conductor insulated wire (not supplied) with 12AWG to 20AWG thickness. Cut the power cable to the length required. Strip approximately 3/8 of an inch of insulation from the power cable wires. Connect the power cables to the unit by fastening the stripped ends to the DC power connector.

Connect the power wires to the DC power source. The Power LED should indicate the presence of power.

Page 4

General and Copyright Notice

This publication is protected by U.S. and international copyright laws. All rights reserved. The whole or any part of this publication may not be reproduced, stored in a retrieval system, translated, transcribed, or transmitted, in any form, or by any means, manual, electric, electronic, electromagnetic, mechanical, chemical, optical or otherwise, without prior explicit written permission of Omnitron Systems Technology, Inc.

The following trademarks are owned by Omnitron Systems Technology, Inc.: FlexPoint[™], FlexSwitch[™], iConverter[®], miConverter[™], NetOutlook[®], OmniLight[®], OmniConverter[®], RuggedNet[®], Omnitron Systems Technology, Inc.[™], OST[™] and the Omnitron logo.

All other company or product names may be trademarks of their respective owners

The information contained in this publication is subject to change without notice. Omnitron Systems Technology, Inc. is not responsible for any inadvertent errors.

Warranty

This product is warranted to the original purchaser (Buyer) against defects in material and workmanship for a period of two (2) years from the date of shipment. A lifetime warranty may be obtained by the original purchaser by registering this product at www.omnitron-systems.com/ support within ninety (90) days from the date of shipment. During the warranty period, Omnitron will, at its option, repair or replace a product which is proven to be defective with the same product or with a product with at least the same functionality.

For warranty service, the product must be sent to an Omnitron designated facility, at Buyer's expense. Omnitron will pay the shipping charge to return the product to Buyer's designated US address using Omnitron's standard shipping method.

Limitation of Warranty

The foregoing warranty shall not apply to product malfunctions resulting from improper or inadequate use and/or maintenance of the equipment by Buyer,

Page 10

WARNING: Note the wire colors used in making the positive and negative connections. Use the same color assignment for the connection at the DC power source.

receptacles on the module

to attach the X.21 device.


4. Connect an appropriate multimode or single-mode fiber cables to the fiber ports of the installed module. It is important to ensure that the transmit (TX) is attached to the receive side of the device at the other end and the receive (RX) is attached to the transmit side. Singlefiber (SF) media converter models operate in pairs. The TX wavelength must match the RX wavelength at the other end and the RX wavelength must match the TX wavelength at the other end

Serial Connector

with the following pin-out configuration:



The X.21 interface is a 2 row DB-15 connector.



Buyer-supplied equipment, Buyer-supplied interfacing, unauthorized modifications or tampering with equipment (including removal of equipment cover by personnel not specifically authorized and certified by Omnitron), or misuse, or operating outside the environmental specification of the product (including but not limited to voltage, ambient temperature, radiation, unusual dust, etc.), or improper site preparation or maintenance.

No other warranty is expressed or implied. Omnitron specifically disclaims the implied warranties of merchantability and fitness for any particular purpose.

The remedies provided herein are the Buyer's sole and exclusive remedies. Omnitron shall not be liable for any direct indirect special incidental or consequential damages, whether based on contract, tort, or any legal theory

Environmental Notices

The equipment covered by this manual must be disposed of or recycled in accordance with the Waste Electrical and Electronic Equipment Directive (WEEE Directive) of the European Community directive 2012/19/EU on waste electrical and electronic equipment (WEEE) which, together with the RoHS Directive 2015/863/EU, for electrical and electronic equipment sold in the EU after July 2019. Such disposal must follow national legislation for IT and Telecommunication equipment in accordance with the WEEE directive: (a) Do not dispose waste equipment with unsorted municipal and household waste. (b) Collect equipment waste separately. (c) Return equipment using collection method agreed with Omnitron

The equipment is marked with the WEEE symbol shown to indicate that it must be collected separately from other types of waste. In case of small items the symbol may be printed only on the packaging or in the user manual. If you have questions regarding the correct disposal of equipment go to www.omniton-systems.com/support or e-mail to Omnitron at intlinfo@omnitron-systems.com.



NOTE: If mounting with a safety ground attachment, use the safety ground screw at the rear of the unit.

2. Insert the SFP fiber transceivers into the SFP

NOTE: The release latch of the SFP transceiver must be in the closed (up) position before insertion

3. Connect the included adapter cable to the serial port on the X21 converter. Use the appropriate gender plug

The serial port on the module is a DE-15 female connector



Page 5

A pinout cross reference table is provided showing the relationship between the serial port and the X.21 interface. A DE-15 to DB-15 adapter cable is provided.

DB-15	DE-15	Description	Circuit	Direction	
Pin	Pin	Description	Name	DTE	DCE
2 9	11 1	Transmit + Transmit -	T (TXD)	In	Out
3 10	2 7	Control + Control -	C (RTS)	In	Out
4 11	8 12	Receive + Receive -	R (RXD)	Out	In
5 12	13 3	Indication + Indication -	l (CTS)	Out	In
6 13	4 9	Signal Element Timing + Signal Element Timing -	S (RXC)	Out	In
7 14	10 14	DTE Signal Element Timing + DTE Signal Element Timing -	X (TXC)	In	Out
1	6	Shield Ground	Shield	N/A	
8	15	Signal Ground	G (GND)	N/A	
15		N/A			

Page 6

Safety Warnings and Cautions

ATTENTION: Observe precautions for handling electrostatic discharge sensitive devices.

WARNING: Potential damage to equipment and personal injury



WARNING: Risk of electrical shock.

Customer Support Information

Phone:	(949) 250-6510	
Fax:	(949) 250-6514	
Address:	Omnitron Systems Technology, Inc.	
	38 Tesla	
	Irvine, CA 92618, USA	
Email:	support@omnitron-systems.com	
URL:	www.omnitron-systems.com	

040-08840-001D 7/23